



Programming adjustments on gas sensor

Settings:	CM-6/CM-12 Default	Change To:
Power Up Test	On	Off
Display	On	On
Buzzer	On	On
Alarm Relay Setting	200 ppm	200 ppm
Alarm Relay Configuration	Normally Open (NO)	Normally Closed (NC)
Fan Relay Setting	35 ppm	50 ppm
Fan Relay Delay	3 minutes	0 minutes
Fan Relay Minimum Runtime	0 minutes	0 minutes
Fan Relay Latching	Off	On
Trouble Fan Setting	Off	Off
4-20mA	bAS (basic)	bAS (basic)
Calibration due	dIS (disabled)	dIS (disabled)

