



Programming adjustments on gas sensor

Settings:	CM-6/CM-12 Default	Change To:
Power Up Test	On	Off
Display	On	On
Buzzer	On	On
Alarm Relay Setting	200 ppm	200 ppm
Alarm Relay Configuration	Normally Open (NO)	Normally Closed (NC)
Fan Relay Setting	35 ppm	50 ppm
Ran Relay Delay	3 minutes	0 minutes
Fan Relay Minimum Runtime	0 minutes	0 minutes
Fan Relay Latching	Off	On
Trouble Fan Setting	Off	Off
4-20mA	bAS (basic)	bAS (basic)
Calibration due	dIS (disabled)	dIS (disabled)

MACURCO
GAS DETECTION

Macurco Inc.
1504 West 51st Street
Sioux Falls, SD 57105
1-877-367-7891



Title: CM-12 Boiler
Wiring
REV 1.0
2-27-2023



All drawings are for reference only. Electrical diagrams / drawings must be reviewed and approved by a local governing authority prior to installation. Macurco makes no representation or warranty concerning wiring diagrams / drawings, and you are to rely solely on the recommendations and requirements of the local governing authority.